
POWERTEC

LEVERAGE

L-CP-S


Manual



PART LIST

Part	Description	Qty	Part	Description	Qty	0
1	Mainframe support tube	1	25	Washer	2	
2	Mainframe	1	26	Safety bar	1	
3	Seat pad	1	27	Spring lock pin	1	
4	Backrest pad	1	28	Backrest adjustment tube	1	
5	Backrest support tube	1	29	Nylon Nut	13	N
6	Backrest adjustment tube	1	30	Washer	14	
7	Rear base	1	31	Plastic bushing	1	
8	Support tube	1	32	Collar lock pin	2	
9	"U"shape arm	1	33	Hand grip	1	
10	Rubber sleeve	2	34	Hex bolt	1	
11	Square inner plug	4	35	Weight holder	1	
12	PVC sleeve	2	36	Rapid lock pin	1	Ť
13	Rect.Inner plug	3	37	Accessory bar	1	
14	Rect.Inner plug	1	38	Connected plate	1	
15	Half-thread hex bolt	2	39	Pocket screw	8	
16	Half-thread hex bolt	- 1	40	Rubber bumper	2	
17	Half-thread hex bolt	2	41	Name plate	1	
18	Half-thread hex bolt	1	42	Pivot	2	
19	Hex bolt	9	43	Round inner plug	4	
- 20	Washer	12	44	Hex bolt	2	
21	Metal bushing	10	45	PVC sleeve	2	
22	Accessory rod	1	46	Half-thread hex bolt	1	
23	Bearing	2	47	Square inner plug	1	_
24	Square inner plug	2	48	PVC sleeve	, P	- S

EXPLODED DIAGRAM




Remarks: All unmarked Washers are (30) and all unmarked Nylon Nuts are (29) . . .

L-CP-S

ASSEMBLY ONE


Before beginning assembly...
Always insert all bolts through holes prior to tightening due to precision fit



L-CP-S


ASSEMBLY TWO





L-CP-S LEVERAGE CHEST PRESS


ASSEMBLY THREE



L-CP-S

ASSEMBLY FOUR





L-CP-S LEVERAGE CHEST PRESS

PERME

THE SECTION

POWERTEC IS NOT LIABLE IF THE TRAINER SHOULD INJURE THEMSELVES WHILE USING **POWERTEC** EQUIPMENT OR WHILE PERFORMING THE TRAINING ROUTINE

POWERTEC

LEVERAGE

POWERTEC, INC.

601 W. Harford St. Milord, PA 18337 Phone: (570) 296-5005 Fax:(570) 296-5009 www.powertecfitness.com

LIFETIME WARRANTY